

HCLK8SS Changing Daylight Savings Transitions

The HCLK can be set to transition into and out of daylight savings automatically. The dates can be set manually, or the Auto-Fill selection will look up the OLD transition dates and enter them for you. The NEW dates are only in clock version 3.2 and later, and can be updated under warranty, or for a nominal charge if out of warranty.

Procedure for entering dates manually:

Cursor to **Setup**, press **Select**

```
Time = 09:35  03/08/00
Channel Status:
  A = off    B = off
  C = off    D = off
  E = off    F = off
  G = off    H = off
Program    Setup
```

Cursor to **Daylight Savings**, press **Select**

```
Time = 09:35
Date = 03/08/00  Wed
Daylight
Savings:      Select
Holidays:    Select
Location:    Select
Utilities:    Select
SAVE         ABORT
```

On **Auto-Fill**, Press Down or Up arrow to turn **Off**.

Cursor Down, and enter **Spring** and **Fall** dates.

Cursor Down and insure **Follow DST?** Is set to **Yes**.

Cursor to **SAVE** and press **Select**.

```
          DST Setup:
Auto fill? Off
Spring:    mm/dd/yy
Fall :     mm/dd/yy
Follow DST? No
Sunrise:   06:08
Sunset :   17:45
SAVE      ABORT
```

Press SAVE or ABORT from SETUP screen to return to the RUN screen!