

Peanut Panel (LP8) Changing Daylight Savings Transitions

The LP8 clock can be set to transition into and out of daylight savings automatically. The dates can be set manually, or the Auto-Fill selection will look up the OLD transition dates and enter them for you. The NEW dates are only in clock version 18 and later, and can be updated under warranty, or for a nominal charge if out of warranty.

Procedure for entering dates manually:

Cursor to **Setup**, press **Select**

```
00:00 01/01/03
A=OFF B=OFF SUNRISE
C=OFF D=OFF 00:00
E=OFF F=OFF SUNSET
G=OFF H=OFF 00:00
PROGRAM  SETUP
```

Cursor to **Daylight Saving Time**, press **Select**

```
Set Time and Date
Daylight Saving Time
Program Holidays
Select Location
Assign Relays/Channel
Clear All Memory
Show Firmware Version
MAIN MENU
```

On **Follow DST**, Press Down or Up arrow to select **Yes**

Cursor Down, and enter **No** for **Use Auto Dates?**

Scroll Down, enter **Begin** and **End** dates for 2007

Cursor to **SAVE** and press **Select**.

```
Daylight Saving Time
Follow DST? Yes
Use Auto Dates? No
Begins on: 03/11/07
Ends on: 11/04/07
SAVE ABORT
```

Press **SAVE** or **ABORT** from **SETUP** screen to return to the **RUN** screen!