

SC-100/ SC-100CP Changing Daylight Savings Transitions

The clock may be set to automatically adjust for transitions from Standard Time (STD) to Daylight Savings Time (DST). From the clock preferences edit screen Daylight Savings may be enabled and the start date and end date for Daylight Savings may be specified. The default setting for Daylight Savings are the old standard setting for most places in the United States.

(This change is perpetual, and will execute each year based on the parameters set, and need only be programmed once)

From Menu, Select Clock Pref's

```
Override Chnls
Edit Schedules
Edit Holidays
Set Time/Date
▶ Clock Pref's
```

Press ENTER

```
▶ Daylt. Sav.?NO
DST Start Date:
1st SUN in Apr.
DST End Date:
Lst SUN in Oct.
```

Preferences screen showing daylight savings parameters.

Daylight Savings Default Settings:

- Daylight Savings *enabled* ("Daylt. Sav.?YES")
- Start date: First Sunday in April
- End date: Last Sunday in October

Use the **UP** or **DOWN** buttons to move the Navigation Pointer to the "Daylt. Sav.?" item and press the **NEXT** button to access the data field. The data field will blink active.

Use the **UP** or **DOWN** button to select "YES" to enable automatic Daylight Savings transition, or "NO" to disable Daylight Savings transition. If Daylight Savings is disabled ("NO"), then the data in the transition start and end date data fields is arbitrary.

Press the **NEXT** button twice to enter the "DST Start Date:" data field.

Use the **UP** or **DOWN** buttons to change the week of the month (1st, 2nd, Lst, etc.) the start date is to occur, then press the **NEXT** button to enter the start date day field.

Use the **UP** or **DOWN** buttons to change the day of the week (SUN, MON, etc.) the start date is to occur, then press the **NEXT** button to enter the month field.

Use the **UP** or **DOWN** buttons to change the month the start date is to occur.

Press the **NEXT** button twice to enter the "DST End Date:" data field.

Use the **UP** or **DOWN** buttons to change the week of the month (1st, 2nd, Lst, etc.) the end date is to occur, then press the **NEXT** button to enter the end date day field.

Use the **UP** or **DOWN** buttons to change the day of the week (SUN, MON, etc.) the end date is to occur, then press the **NEXT** button to enter the month field.

Use the **UP** or **DOWN** buttons to change the month the end date is to occur.

Parameters for 2007 should be set to:

START- 2nd SUN in Mar
END- 1st SUN in Nov.

After the Daylight Savings parameters have been set, use either the **NEXT** button to continue through other preference settings or navigate the pointer down to "ENTER TO SAVE" at the bottom of the screen and press the **ENTER** button to save the settings to memory.